

## INSTALLING BRUSH PLATE ASSEMBLY

**WARNING!!!** ALWAYS USE PROPER EYE PROTECTION WHEN PERFORMING ANY MECHANICAL REPAIRS TO A VEHICLE – INCLUDING, BUT NOT LIMITED TO, ANY INSTALLATION AND OR REPAIRS TO THE DELCO REMY STARTER. FAILURE TO USE PROPER EYE PROTECTION CAN LEAD TO SERIOUS AND PERMANENT EYE DAMAGE.

Only perform the mechanical functions that you are properly qualified to perform. Mechanical repairs that are beyond your technical capabilities should be handled by a professional installation specialist.

**NOTICE!** FOLLOW ENGINE AND/OR VEHICLE MANUFACTURER'S INSTRUCTIONS CAREFULLY WHEN REMOVING AND INSTALLING THE STARTERS.

1. If field coil leads and ground leads are too short to reach this new brush holder:
  - a. Assemble the clips under brush lead screws.
  - b. Attach field coil leads and ground leads to the clips.
  
2. These clips will be needed only where the field lead terminals are straight and not "L" shaped.

Ref: 1988121